



507-42, 509-42, 510-42,
510-56, 512-56, 514-56

QUICK REFERENCE GUIDE


This Quick Reference Guide DOES NOT replace the Operators Manual. You MUST read ALL the disclaimers and safety and other instructions in the Operators Manual before initially operating this product. Accordingly, no legal claims can be entertained based on the data, illustrations or descriptions in this Quick Reference Guide.

BEST PRACTICES


1. Carry a load as low as possible while maintaining good visibility.
2. Forks should be tilted back when in transport – with or without a load, cradle the load.
3. Fork tips should be on the ground when unit is parked.
4. Rather than driving into the load, extend the boom to easier see the forks in the load.

Static Dimensions


Machine model	506-36	507-42	509-42	510-42	510-56	512-56	514-56
A Overall height	ft-in	8-3		8-10		8-11	
B Overall width over tyres	ft-in	7-10		8-1			
C Inside width of cab	ft-in	3-1					
D Front track	ft-in	6-4		6-7			
E Wheelbase	ft-in	10-4					
F Overall length to front tyres	ft-in	17-1	17-8	17	17-8	17-9	18-4
G Overall length to front of carriage	ft-in	19-5	21-3	20-7	21-3	21-7	22-4
H Ground clearance	ft-in	1-3.5		1-5.5			
Weight	lbs	20,270	21,300	22,430	23,858	29,900	30,635
							32,143



Tie Down Points




Front Anchor Points




Rear Anchor Points

Cab Layout




1. Steering Wheel
2. Accelerator Pedal
3. Foot Brake Pedal
4. Park Brake Lever
5. Transmission Lever (4-Speed Transmission)
7. Steer Mode Selector
8. Console Switches
9. Multi-Purpose Steering Column Switch (4-Speed Transmission)
10. Starter Switch
11. Instrument Panel
12. Hourmeter
13. Boom and Carriage Controls
14. Auxiliary Controls
15. Chassis Leveling (Sway) Controls
16. Stabilizer Controls (if fitted)
17. Air Conditioning and Cab Heater Controls
18. Load Charts
19. Inclinometer

Instrument Panel









- | | |
|------------------------------|--------------------|
| A. Tachometer | E. Warning Lights |
| B. Hourmeter | F. Digital Display |
| C. Coolant Temperature Gauge | G. Warning Lights |
| D. Fuel Level Gauge | |





- | |
|--|
| A. Malfunction Indicator Lamp (MIL) |
| B. Not used |
| C. RAS System – Cushioned Mode Indicator |
| D. RAS System – Locked Mode Indicator |
| E. Hydraulic Isolation – Fault Indicator |
| F. RAS System – Fault Indicator |
| G. Not used |
| H. Right-Hand Stabilizer Indicator |
| I. Left-Hand Stabilizer Indicator |

Start Up Sequence

<p>1. Insert Isolator Key (A)</p> <p>Insert battery isolator key switch, push and turn 90° (degrees symbol)</p> 	<p>2. Disarm the immobiliser</p> <p>If installed, clear with MID then key in the code followed by enter.</p> 	<p>3. Set to Neutral</p> <p>Put the forward / reverse lever into neutral.</p> 
<p>4. Insert Key</p> <p>Insert key into ignition switch (A)</p> 	<p>5. Start Machine</p> <p>Turn the ignition key to the start position (position II) and hold it there until the engine starts.</p> 	<p>6. Operate Hydraulics</p> <p>Operate the hydraulic services to make sure that each function is working correctly and to help warm up the hydraulic system.</p> 




Single Lever Control



- A. Boom Raise
- B. Boom Lower
- C. Boom Extend
- D. Boom Retract

- E. Carriage Tilt Forward
- F. Carriage Tilt Back
- G. Inner Boom



Auxiliary Control



Roll the thumb switch (E) forward or (F) backwards to use desired function


Stabilizer Controls

1. Park the machine on firm ground.
2. Turn off the stabilizer isolation switch (D).
3. Push the control levers (B) forward to lower the stabilizer legs (F).
4. Pull the control levers (C) back to raise the stabilizer legs (E).
5. Before you operate the boom, make sure the machine is level and stabilizer controls are isolated.




- A. Stabilizer control levers
- B. Stabilizer legs- lower
- C. Stabilizer legs – raise
- D. Stabilizer isolation switch

Chassis Levelling (Sway) Operation




To operate move the lever to either the right or left until the machine shows as level on the inclinometer.




Vehicle Steer Mode - Manual

1. Stop the machine. Set the gear lever to the neutral position
2. Turn the steering wheel until all the wheels are pointing in the straight ahead position
3. Use the lever (A) to select the steering mode:
 - B. 4 wheel steer
 - C. 2 wheel steer
 - D. Crab steer
4. Operate the steering wheel until the wheels straighten up to re-phase the mode.



Access Covers


Engine Compartment



- A. Air Filter
- B. Transmission Oil Dipstick
- C. Water Separator
- D. Radiator
- E. Engine Oil Filter
- F. Drive Belt Guard
- G. Engine Oil Dipstick
- H. Engine Oil Filler Cap
- J. Coolant Expansion Tank


Access Covers

Battery Compartment












1. Make the machine safe.
2. Hold the battery cover, then remove the bolts (A)
3. Open cover (B).

Rear Cover




1. Make the machine safe.
2. Hold the lift arm cover (A), then remove the bolts (B)
3. Lower the cover.

Connecting Attachments



JCB 509 42
NORTH AMERICA




JCB 509 42
NORTH AMERICA

PSI	TIRE SIZE	PR	PSI
81	1400-24	16	81

INFLATION PRESSURES FOR PNEUMATIC TIRES ONLY.

TIRES ON THIS VEHICLE MAY CONTAIN SEALANT OR FOAM BALLAST.

JCB 509 42
NORTH AMERICA




JCB 509 42
NORTH AMERICA

PSI	TIRE SIZE	PR	PSI
81	1400-24	16	81


INFLATION PRESSURES FOR PNEUMATIC TIRES ONLY.


TIRES ON THIS VEHICLE MAY CONTAIN SEALANT OR FOAM BALLAST.

JCB 509 42
NORTH AMERICA




JCB 509 42
NORTH AMERICA






JCB 509 42
NORTH AMERICA




JCB 509 42
NORTH AMERICA






JCB 509 42
NORTH AMERICA


PALADIN 10000 LB & 12000 LB 60" FORK POSITIONER




NO TIRE BALLAST
60" FORK POSITIONER
60" PALLET FORKS

400/F7360 OR
400/F7377





JCB 509 42
® NORTH AMERICA



NO TIRE BALLAST
 48" & 66" & 72" SIDE SHIFT/TILT & STANDARD CARRIAGES
 48" AND 60" PALLET FORKS
 6 OFF BLOCK TINES






JCB 509 42

NORTH AMERICA

STAR INDUSTRIES EXTENDABLE BOOM MODEL 1360B




POSITION	1	2	3	4
A	3000 LB	2000 LB	1750 LB	1250 LB
B	2000 LB	1750 LB	1500 LB	1250 LB
C	1500 LB	1250 LB	1250 LB	1000 LB
D	1000 LB	750 LB	750 LB	750 LB


NO TIRE BALLAST
 72" STANDARD CARRIAGE
 48" AND 60" PALLET FORKS
 48" BRICK FORKS



JCB 509 42
NORTH AMERICA




JCB 509 42
NORTH AMERICA






JCB 509 42
® NORTH AMERICA




JCB 509 42
® NORTH AMERICA





JCB 509 42
® NORTH AMERICA



JCB 509 42
® NORTH AMERICA

